

## Reset to Factory Defaults

---

### Reset to USB Factory Defaults



M0001\_01

## Reset to Factory Defaults

---

### Reset to USB Factory Defaults



M0001\_01

### Reset to RS232 Factory Defaults



M0017\_01

**Note:** The CR1000 Configuration Guide is available at [www.codecorp.com](http://www.codecorp.com)

### Reset to RS232 Factory Defaults



M0017\_01

**Note:** The CR1000 Configuration Guide is available at [www.codecorp.com](http://www.codecorp.com)

## To Detach a Cable

---

Press a paper clip into the hole on the back of the CR1000, and gently pull the cable from the reader.



## To Detach a Cable

---

Press a paper clip into the hole on the back of the CR1000, and gently pull the cable from the reader.



14940 S. Pony Express Rd. Bluffdale, UT 84065  
[www.codecorp.com](http://www.codecorp.com) (801) 495-2200



14940 S. Pony Express Rd. Bluffdale, UT 84065  
[www.codecorp.com](http://www.codecorp.com) (801) 495-2200

## Code Reader 1000



The CR1000 is shipped with one of the following cables:



6" USB  
Straight Cable



8" RS232 Coiled Cable  
w/ Power Supply

### Using the CR1000

1. For USB: to power up the reader, simply plug the USB cable provided into the reader and USB port on the host device. After several seconds, the unit will beep twice, the LED will turn off and the CR1000 is ready for use.

For RS232: to power up the reader, simply plug the RS232 cable provided into the reader, plug the Power Supply into the AC outlet, plug the power supply cord into the barrel jack on the cable, and lastly connect the cable to the appropriate serial port on the host device.

After several seconds, the unit will beep twice, the LED will turn off and the CR1000 is ready for use.

2. The blue bars are used for aiming, center the bars in the center of a bar code and press the trigger to scan.

The optimal reading distance is approximately 4.0" (10 cm).



## Code Reader 1000



The CR1000 is shipped with one of the following cables:



6" USB  
Straight Cable



8" RS232 Coiled Cable  
w/ Power Supply

### Using the CR1000

1. For USB: to power up the reader, simply plug the USB cable provided into the reader and USB port on the host device. After several seconds, the unit will beep twice, the LED will turn off and the CR1000 is ready for use.

For RS232: to power up the reader, simply plug the RS232 cable provided into the reader, plug the Power Supply into the AC outlet, plug the power supply cord into the barrel jack on the cable, and lastly connect the cable to the appropriate serial port on the host device.

After several seconds, the unit will beep twice, the LED will turn off and the CR1000 is ready for use.

2. The blue bars are used for aiming, center the bars in the center of a bar code and press the trigger to scan.

The optimal reading distance is approximately 4.0" (10 cm).

